

Primero desinstalamos, con:

```
opkg remove kmod-mt7915-firmware
opkg remove kmod-mt7915e
opkg remove kmod-mt76-connac
opkg remove kmod-mt76-core
opkg remove kmod-mac80211
opkg remove wpad-basic-mbedtls
opkg remove hostapd-openssl
opkg remove hostapd-common
opkg remove kmod-cfg80211
opkg remove wireless-regdb
opkg remove iwinfo
opkg remove iw
rm /etc/config/wireless
reboot
```

Luego, volvemos a instalar, con:

```
opkg install kmod-mt7915-firmware
opkg install hostapd-openssl
```